

MINOR

XS

MSF

MASS

SURFACE FINISHING

OUR EXPERIENCE, YOUR RESULTS



ROLL

WASCH



MINOR XS



MINOR-XS-6



MINOR-XS-6-XT

Modello Model	Capacità lt. Capacity lts.	Dotazioni di serie Standard features
Minor XS 3	3	CC - TT - 2F - EP
Minor XS 3 XT	3	CC - 2F - EP
Minor XS 6	6	CC - TT - 2F - EP
Minor XS 6 XT	6	CC - 2F - EP
Minor XS 6 GM	6	2F - EP

The series **Minor XS** offers professional, reliable and flexible machines, in compact sizes, ideal for laboratories and finishing of small parts.

The various models of the **Minor XS** series are distinguished by a number of features and options, summarized below and shown in the above table. Features and components:

CC = Central cylinder removable

TT = Transparent top (polycarb. cover)

2F = 2 filters set (1 filter and 1 cap)

EP = Electric switch on/off and Schuko plug

All models have three feet of polyurethane to be fixed to the workbench.

MINOR


XS



Minor XS 6 GM con cilindro centrale fisso
Minor XS 6 GM with fixed central cylinder



Minor XS 6 XT senza cilindro centrale
Minor XS 6 XT without central cylinder



Acessori smontati
Dismounted accessories

The series **Minor XS** offers real vibratory finishing machines, with professional services and a full range of accessories, for finishing processes both wet and dry.

MINOR-XS is an extremely versatile machine with thousands of applications.

Possible applications:

JEWELLERY, COSTUME JEWELLERY brightening and polishing, stone processing.

INDUSTRY - surface finishing of small batches for the following articles: high precision, medical, prosthesis/surgery, electronics, watches, micro-components, micro-casting, fine-shearing, etc.


HOBBY - cleaning, polishing, hunting/fishing, maintenance, reparation, ageing etc.



alcuni esempi, by Rollwasch®



few examples, by Rollwasch®



Minor XS 6 + Splitter 4 XS6



Minor XS 6 + Splitter 4 XS6

The series **Minor XS** offers the possibility to approach the world of vibratory finishing in a simple and practical way.

Minor XS 6, for example, without the central cylinder, it can carry out treatments for cleaning and polishing of large objects and complex as a lampshade made of steel wire with glass pendants. With the cylinder mounted, it can shine more small articles of various types and materials.

Minor XS 6 with accessory **SPLITTER 4 XS6**, for example, can work components for the dental, or remove greasy and waxy components of coffee vending machines and many other possible applications.



Minor XS 6 PRO



Modello Model	Materiale Telaio Frame Material	Comando Vibratore Vibrator Control	lt. lt.	Pompa Pump	Stelo gas Gas spring	Tavolo Table	Vibro Wet Wet Vibe	Vibro Dry Wet Vibe	Minimag Minimag
MINOR-XS-3-PRO	ALU	e. timer	3	-	OK	-	-	-	-
MINOR-XS-6-PRO	ALU	e. timer	6	-	OK	-	-	-	-
MINOR-XS-6-GM-PRO	ALU	on/off	6	-	OK	-	-	-	-
MINOR-XS-3-PROL	LASER-STEEL	e. timer	3	-	-	-	-	-	-
MINOR-XS-6-PROL	LASER-STEEL	e. timer	6	-	-	-	-	-	-
MINOR-XS-6-GM-PROL	LASER-STEEL	on/off	6	-	-	-	-	-	-

ALU = alluminio profilato; aluminium profiles;
LASER-STEEL = acciaio taglio laser; laser-cut steel;
e.timer = temporizzatore elettronico; electronic timer/switch;
on/off = selettore marcia/arresto; selector switch;
Connessione: 230 Volt/50 Hz/Monofase; Per presa Schuko; **Connection:** 230 Volt/50 Hz/Singlephase; Schuko plug;
 - = Non previsto; - = Not foreseen; **OK** = incluso; **OK** = included;

Minor XS PRO Series represents the evolution of project Minor XS, with the possibility of reversing the working bowl at the end of the cycle.

MINOR XS PRO series is distinguished by an aluminum frame profile, complete with gas spring, rollers for tilting, a hand lever for a comfortable grip, an elegant and functional design.

The electric switch can be characterized alternatively by an electronic digital timer programmable, or by an on-off switch.



Minor XS 6 GM PROL




Modello Model	Materiale Telaio Frame Material	Comando Vibratore Vibrator Control	lt. lt.	Pompa Pump	Stelo gas Gas spring	Tavolo Table	Vibro Wet Wet Vibe	Vibro Dry Wet Vibe	Minimag Minimag
MINOR-XS-3-PRO	ALU	e. timer	3	-	OK	-	-	-	-
MINOR-XS-6-PRO	ALU	e. timer	6	-	OK	-	-	-	-
MINOR-XS-6-GM-PRO	ALU	on/off	6	-	OK	-	-	-	-
MINOR-XS-3-PROL	LASER-STEEL	e. timer	3	-	-	-	-	-	-
MINOR-XS-6-PROL	LASER-STEEL	e. timer	6	-	-	-	-	-	-
MINOR-XS-6-GM-PROL	LASER-STEEL	on/off	6	-	-	-	-	-	-
MINOR-XS-6-PRO-K2-WD	ALU	e. timer	6	1	OK	2 pos.	1	1	-
MINOR-XS-6-PRO-K3-WDM	ALU	e. timer	6	1	OK	3 pos.	1	1	1
MINOR-XS-6-PROL-K2-WD	LASER-STEEL	e. timer	6	1	-	2 pos.	1	1	-
MINOR-XS-6-PROL-K3-WDM	LASER-STEEL	e. timer	6	1	-	3 pos.	1	1	1
MINOR-XS-6-GM-PROL-K2-WD	LASER-STEEL	on/off	6	1	-	2 pos.	1	1	-
MINOR-XS-6-GM-PROL-K3-WDM	LASER-STEEL	on/off	6	1	OK	3 pos.	1	1	1
MINI-MAG-15-V-GM	LASER-STEEL	timer+vre *	15	-	-	-	-	-	-

* Unità magnetica: timer+vre = timer+variaz. frequenza e inversione
 * Magnetic unit: timer+vre = timer+frequency control with inversion
 Altre sigle e abbreviazioni, vedi legenda alla pagina precedente; Other id or abbreviations, see legenda at previous page:

The series of machines **Minor XS PRO** and **PROL**, single or **Komby**, constitute a wide program.

The **MINOR-XS-PROL** stands for the frame steel chassis, laser cut, bent and painted gray ice RAL-7035. The electric switch can be characterized alternatively by an electronic digital timer programmable, or by an on-off switch.

The design "PROL" also combines the functionality to the competitiveness, especially in the GM version.



Minor XS 6 PRO K2 WD



Mini Mag 15 V GM



Minor XS 6 PROL K2 WD



Minor XS 6 PRO K2 WD



Minor XS 6 PRO K2 WD



Minor XS 6 PROL K2 WD

The Series **Minor XS PRO K2 / K3** represents the evolution of project Minor XS PRO, with the ability to combine multiple machines, also type “MINI-MAG” in a rational workstation.

The “Kombi” versions are the combination of at least two vibratory units with or without MINI-MAG (magnetic) accessory unit. A steel frame holds the vibrators that can be DRY or WET, with one dosing pump, automatically activated, and a lower effluent reception tank.

Both tilting vibrators can discharge in a suitable tank, with stainless steel sieve.

The **MINI-MAG-15-V-GM** unit has one transparent interchangeable bowl of 15 lts. nominal capacity.

See table of several models on page 6.



VIA SAN CARLO, 21
20847 ALBIATE (MB) - ITALIA



TEL. +39 0362 930334
FAX. +39 0362 931440
E-MAIL INFO@ROLLWASCH.IT



WWW.ROLLWASCH.COM
PERFECT SURFACES SINCE 1950

OUR EXPERIENCE, YOUR RESULTS

